




CLIFF


JACK SOCKET S2S



FCR1210 - S2S/BNB/PCC/WN
MONO JACK SOCKET WITH PC LEGS
SUPPLIED WITH BLACK PLASTIC NUT





SWITCH CONTACTS OPEN WHEN
PLUG IS INSERTED, CLOSE WHEN
PLUG IS WITHDRAWN.







SWITCH CONTACTS OPEN WHEN
PLUG IS INSERTED, CLOSE WHEN
PLUG IS WITHDRAWN.



FCR1215 - S2S/BBB/PCC/WN
STEREO JACK SOCKET WITH PC LEGS
SUPPLIED WITH BLACK PLASTIC NUT



FCR1210W - S2S/BNB/PCC/EW/N
MONO JACK SOCKET WITH PC LEGS AND FITTED EARTH WASHER WITH 2 PC LEGS
SUPPLIED WITH BLACK PLASTIC NUT



FCR1210WMN - S2S/BNB/PCC/WM/N/FW
MONO JACK SOCKET WITH PC LEGS AND FITTED EARTH WASHER WITH 1 PC LEG
SUPPLIED WITH FIBRE WASHER AND BLACK PLASTIC NUT

